

RIFTEK
Sensors & Instruments



PORTABLE RAIL PROFILOMETER

PRP Series

User's manual

www.riftek.com
info@riftek.com

Contents

1.	Safety precautions and measurement conditions	5
2.	CE compliance.....	5
3.	Laser safety.....	5
4.	General information	5
4.1.	Controlled parameters.....	5
5.	Basic technical data.....	6
6.	Complete set to be supplied.....	6
6.1.	PDA software licensing	7
7.	Structure and operating principle	7
7.1.	Basic components of the device and their functions	7
7.1.1.	Laser scanning module.....	8
7.1.2.	Display device (PDA)	8
8.	Operating principle.....	9
9.	Rail parameters under control.....	9
9.1.	L-parameters	9
9.2.	Geometric parameters of the rail under control	10
10.	Application installation.....	10
11.	Adding and selecting a measuring device	10
12.	Setting up PDA software	15
12.1.	General settings.....	15
12.1.1.	Password.....	16
12.1.2.	Bluetooth	17
12.1.3.	Language.....	17
12.2.	General measurement parameters.....	18
12.3.	Data export.....	18
12.3.1.	Export to PDA.....	19
12.3.2.	Export to PC database.....	20
12.3.2.1.	PC server settings.....	20
12.3.2.2.	PDA server settings	23
12.3.3.	Sending data via email.....	24
12.4.	PRP measurement parameters.....	25
12.4.1.	Calculation methods.....	25
12.4.2.	Calculated parameters	26
12.4.3.	L parameters.....	27
13.	Setting reference profiles and tolerances	28
13.1.	Reference profile	28
13.1.1.	Selecting and deleting the reference profile	28
13.1.2.	Uploading the reference profile to the database	30
13.2.	Tolerances.....	30
13.2.1.	Viewing and deleting tolerances.....	30
13.2.2.	Adding tolerances	31
14.	PDA software update.....	34
15.	Measurement procedure	35
15.1.	Turning on the profilometer	35
15.2.	Mounting onto the rail	36
15.3.	Quick setup.....	36
15.4.	Measurement.....	37
15.4.1.	Saving the measured profile.....	39
16.	Browsing the database	40
16.1.	Data export.....	41
16.2.	Data deletion.....	43
16.3.	Data filtering.....	44

- 16.4. Viewing measurement results47
 - 16.4.1. Saving a profile as a reference.....47
 - 16.4.2. Viewing rail parameters.....48
 - 16.4.3. Graphic representation of the rail profile.....49
- 17. Data exchange between smartphone and PC49
 - 17.1. Wi-Fi data transfer settings49
 - 17.2. Wireless data transfer51
 - 17.2.1. Transferring the database file to the PC.....51
 - 17.2.2. Transferring the reference profile file.....51
 - 17.2.3. Importing the Railset.xml file51
- 18. Installing software on PC52
 - 18.1. Database support software installation.....52
 - 18.2. Synchronization of mobile device and PC53
 - 18.3. Launching the software.....53
- 19. User settings of the program.....54
 - 19.1. Parameter settings.....54
 - 19.1.1. "Rail parameters" tab54
 - 19.1.2. "Calculated parameters" tab.....55
 - 19.1.3. "L-parameters" tab55
 - 19.1.4. "Measurement method" tab.....55
 - 19.1.4.1. Selection of measurement units55
 - 19.2. Database settings56
 - 19.2.1. Setting the path to database56
 - 19.2.2. Creation of empty database57
 - 19.2.3. Import of database57
 - 19.2.4. Language selection.....58
 - 19.2.4.1. Preparation and installation of the language support file58
 - 19.3. Registration data.....58
 - 19.3.1. Registration of organizations.....58
 - 19.3.2. Registration of operators.....59
 - 19.3.3. Registration of reference profiles59
 - 19.3.3.1. Request and registration of the profile file60
- 20. Working with profilograms and wear calculations61
 - 20.1. Browsing the graph and profile coordinates.....61
 - 20.2. "Parameters" tab.....62
 - 20.2.1. Selecting a profile to compare.....62
 - 20.2.2. Selecting L-parameters values.....62
 - 20.2.3. Geometric parameters of the profile63
 - 20.3. Wear calculation63
 - 20.3.1. Fast wear calculation63
 - 20.4. Browsing and saving a profile63
 - 20.4.1. Export to Excel, DXF, REF.....64
 - 20.5. Alignment of profiles64
 - 20.6. Superposition of profiles.....65
 - 20.7. Rescaling.....65
- 21. Viewing and editing data66
 - 21.1. Viewing and filtering data66
 - 21.2. Editing data.....67
 - 21.3. Report preparation68
 - 21.3.1. Excel-format report69
 - 21.3.2. Report for printout.....69
- 22. Taking measurements under PC control (without PDA)70
 - 22.1. Calibration.....71
 - 22.1.1. Bluetooth connection.....71
 - 22.1.2. Calibration of the profilometer72
 - 22.2. Measurement by using PC.....73
 - 22.2.1. Saving data.....73

23.	Annex 1. Charging procedure	74
24.	Annex 2. Testing and calibration	74
24.1.	Preparation for testing/calibration	74
24.2.	Calibration.....	75
25.	Warranty policy	76
26.	Revisions	76
27.	Distributors.....	77
28.	RIFTEK's measurement instruments for railway transport.....	81

1. Safety precautions and measurement conditions

- Prior to mounting the profilometer onto the rail, areas of contact and laser scanning of the rail surface should be thoroughly cleaned from dirt.
- When mounting the module on the rail, do not allow heavy shocks of its support against the rail.
- The output windows of the laser sensor must be carefully inspected and cleaned.
- Do not use laser module in locations close to powerful light sources.


2. CE compliance

The profilometer has been developed for use in industry and meets the requirements of the following Directives:

- EU directive 2014/30/EU. Electromagnetic compatibility (EMC).
- EU directive 2011/65/EU, "RoHS" category 9.

3. Laser safety

The profilometer makes use of a c.w. 660 nm wavelength semiconductor laser. Maximum output power is 1 mW. The device belongs to the 2 laser safety class. The following warning label is placed on the profilometer body:



The following safety measures should be taken while operating the profilometer:

- Do not target laser beam to humans.
- Do not disassemble the sensor.
- Avoid staring into the laser beam.

4. General information

Portable Rail Profilometer (PRP) is designed for non-contact registration of the cross-section of the railhead acting face.

The main functions of PRP are as follows:

- Obtaining information on the cross-section profile of the railhead acting face.
- Full profile scanning and analysis of the railhead acting face.
- Visualization of combined graphic images of the actual and new cross-section profiles of the railhead.

4.1. Controlled parameters

- Railhead vertical wear (Hv).
- Side wear (Hh), that is measured 13 mm lower the top of railhead and side wear (Hh_{R45}), that is measured at 45 degrees relative to the rail symmetry axes at the point that passes through the center of lateral working fillet.
- Reduced head wear, that is determined as vertical one + the half of lateral wear, namely: $Hr = Hv + 0,5Hh$ or $Hr = Hv + 0,5Hh_{L_{R45}}$.

5. Basic technical data

Parameter	Value
Railhead vertical wear, mm	from -15.0 to +20.0
Lateral railhead wear, mm	from -15.0 to +20.0
Redused railhead wear, mm	up to 20.0
Scanning angle inside the rail track, degrees	108
Scanning angle outside the rail track, degrees	108
Measurement error, not more than, mm	±0.1
Scanning time, sec	10-12
Laser module dimensions, mm	Fig. 3
Power supply, laser module	3.7V Li-ion battery, 6800mAh
Power supply, PDA	3.7V Li-polymer battery, 3300mAh
Number of measurements that can be taken before battery recharge, not less than	500
PDA memory capacity	100 000 measurements
Interface between a laser module and PDA	Bluetooth

6

6. Complete set to be supplied

Designation	Name	Quantity	Weight, kg
RF303	PDA	1	0.4
RF570	Laser scanning module	1	4.0
RF570.40	Charging device 5V 1.0A for PDA and laser module	2	0.2
RF570.42	Universal cable (USB-port)	1	
RF570.43	Bluetooth-adapter	1	
RF570.30	Packing case	1	1.5
PRP_DB	Database management system (CD)	1	
RF570UM	User's manual	1	
	Calibration tools (optional):		
RF570.20.100	Calibration unit		3
RF570Calibr	Software		

* The profilometer may be supplied without a PDA. In this case, to operate the gauge, an Android-based device (smartphone or tablet) with licensed software (paid license) is required. The software can be downloaded from the website:

<https://riftek.com/upload/medialibrary/d15/rhed80h13jb9ndrvl9n3ycnyar96wc6/prp.zip>

The software for maintaining the electronic database of rail wear is available on the website for free download:

https://riftek.com/upload/medialibrary/e3d/dif6fhqwej3kzdhmlltw71tn8bwkdkex/Install_Prp_db_6.15.3.1_b182.zip

The laser profilometer is supplied in a special protective case that prevents the device from being damaged during transportation.

6.1. PDA software licensing

By default, the PDA is configured to operate with the PRP device it was supplied with. One software license allows the PDA to connect to a single PRP device.

A single PDA can support an unlimited number of licenses for operation with an unlimited number of devices.

A single license can be installed on an unlimited number of PDAs.

7. Structure and operating principle

7.1. Basic components of the device and their functions

Figure 1 shows basic components of the device.




Figure 1

- (1) Display device (personal digital assistant, PDA).
- (2) Laser scanning module

7.1.1. Laser scanning module

The module is intended for laser scanning of rail surface.




Figure 2

- (1) ON/OFF button
- (2) Indicator of Bluetooth connection (blue LED)
- (3) Indicator of turn ON (red LED)
- (4) Support for mounting of the device on the rail
- (5-6) Clamps for mounting of the device on the rail head
- (7) Input window of laser sensor
- (8) Output window of laser sensor

Overall dimensions of scanning module are shown in Figure 3.




Figure 3

7.1.2. Display device (PDA)

The display device (PDA) is designed to control the laser scanning module, receive data from the scanning module, display measurement results, input parameters, and store data.



Figure 4

Figure 4 shows the following:

- 1 – Power button.
- 2 – Charging port.

8. Operating principle

The operator mounts the laser scanning module onto the railhead to be measured. Upon command from the PDA or PC, the laser module performs a non-contact scan of the rail surface. The measurement results (geometrical parameters and surface profile) are displayed on the PDA screen, can be saved in the PDA memory, and transferred to the PC database. Additional parameters are also saved, including the measurement date, operator code, track distance, track number, rail type, etc.

9. Rail parameters under control

9.1. L-parameters

Geometric parameters of the rail are calculated automatically after laser scanning of the rail is completed. To calculate geometric parameters, use is made of reference points on the railhead. Location of the reference points is shown in Figure 5 and is defined by **L-parameters**. Values of L-parameters preset in PDA are given in Table 1 and can be changed by user.




Figure 5

Table 1.

L-parameter	Default value	Description
L1	13 mm	Used for calculation of lateral railhead wear.
L2	20 mm	Used for calculation of railhead width.

9.2. Geometric parameters of the rail under control


The parameters under control and respective calculation methods are given in Table 2.

Table 2.

Parameter	Designation	Calculation method
Railhead vertical wear	Hv	is calculated as a difference between the measured value and nominal value of new rail in direction of rail axis of symmetry
Lateral railhead wear	Hh	is measured at the height of L1 = 13 mm from the rolling surface of rail head
Lateral railhead wear at the angle of 45 degrees	Hh45	is measured at 45 degrees relative to the rail symmetry axis at the point that passes through the center of lateral working fillet
Reduced railhead wear	Hr	is determined as vertical one + the half of lateral wear, namely: $Hr = Hv + 0,5Hh$.
Reduced railhead wear at 45 degrees	Hr45	is determined as vertical one + the half of lateral wear at 45 degrees, namely: $Hr45 = Hv + 0,5Hh45$
Railhead width	W	is measured at the height of L2 from the rolling surface of rail head

10. Application installation

If the PRP was supplied without a PDA, to install the application, run the file **prp.apk** and grant all required permissions.




If the permissions are denied, the device will not function properly, and a warning message will be displayed.

11. Adding and selecting a measuring device

By default, the PDA is configured to operate with the PRP device it was supplied with. To add a new device, follow the instructions provided below.


Go to the **Tools** menu by either tapping the menu icon  or swiping from the left edge of the device toward the center of the screen.




Here you can enable or disable Bluetooth, select the type of measuring device (default is IKP), and add a new measuring device depending on the selected type.

To add a device, turn it on and tap the **SCAN FOR DEVICES** button.


If the search is successful, the device will be added to the **AVAILABLE DEVICES** list. To pair, tap on the detected device.




The device will be paired but locked for selection as the primary device for synchronization (🔒). To unlock it and set it as the primary, swipe the entry from right to left and tap the **SELECT** button.




In the pop-up window, you must enter the key or scan the QR code. The unique key or QR code is provided with the measuring device or upon request. If the key is incorrect, an error message will appear.




To scan the QR code, you must allow the application to take photos and videos.






13 If the correct key is entered, the lock icon will disappear, and a check mark (✓) will appear on the selected device.



The selected device will connect automatically when the application starts. Later, if the desired device is listed (and unlocked), it can simply be selected.




If the measuring device will no longer be used, it can be removed from the list of available devices by unpairing it. To do this, swipe the entry from right to left and tap the **Delete** button.



12. Setting up PDA software


Before starting work with the device, the software must be configured. To do this, select the **General settings** item in the menu:

15




12.1. General settings

Selecting the **General** item opens a window for setting up the password and Bluetooth connection:




12.1.1. Password

The **Password settings** item allows you to set a password to access all basic settings.




To set a password, you need to select the **Password** item, enter the password and confirm the entry. The default password is "1111".



12.1.2. Bluetooth

The **Bluetooth settings** section allows you to configure the Bluetooth activation mode and the connection behavior of the selected measuring device when the application starts.



Autoconnection – if this option is enabled, the application will attempt to connect to the measuring device selected in the settings upon startup (see [Adding and selecting a measuring device](#)).

If this option is disabled, to establish a connection with the device, you must tap the synchronization icon in the main window of the application.


Turn on confirmation – this option becomes available only if the **Autoconnection** option is selected. When enabled, the application will prompt for confirmation to enable Bluetooth at startup.

12.1.3. Language

Changing the application language is performed upon request to the manufacturer (info@riftek.com) and is a free service.

12.2. General measurement parameters

Selecting the **Measurement** item opens a window for configuring the measurement parameters.



18


Units – you can choose mm or inches.

Show chart – this option allows the measured rail profile image to be displayed.

Align measured profile – automatic alignment of the measured profile with the selected reference profile. If the option is not selected, no alignment is performed after the measurement. The profile's tilt angle and its displacement along the X and Y axes are calculated based on the device calibration.

12.3. Data export


Selecting the **Data export settings** item opens a window to configure options for exporting saved data:




12.3.1. Export to PDA

To enable data file saving on the smartphone, check the **Save to smartphone** option.

19




Next, select the desired file format (CSV, XLS, XML).



12.3.2. Export to PC database

To enable data export, select the **PRP_DB database** option.


**20**

To enable data transfer between the mobile device and the PC, the PC's IP address must be configured. Data exchange is carried out via Wi-Fi. The PC and the mobile device must be connected to the same Wi-Fi network. This can be either a dedicated network created on the Android device (a virtual hotspot) or any home/office network.

12.3.2.1. PC server settings

To transfer data to the PC, you must specify the IP address of the server running in **Prp_DB**. Download link for the **Prp_DB** application:


https://riftek.com/upload/medialibrary/e3d/dif6fhgwej3kzdhmltw71tn8bwkdkex/Install Prp_db 6.15.3.1 b182.zip




The IP address can be determined on the PC. There are two ways to find your IP address in Windows.

Method 1. Find the IP address using the **Settings** app (Windows 10).

1. Select **Start > Settings**.




2. Select **Network & Internet**.



3. In the left panel, select **Wi-Fi**.



4. Click on your network or connection name.
5. Scroll down to the IPv4 address – this is your IP address.




Method 2. Find the IP address using the command line.


1. Click **Start**, type *cmd* in the search bar and press **Enter**.




2. Type *ipconfig* and press **Enter**.



3. Find the IPv4 address – this is your IP address.




This IP address must be specified in the PC server settings.
 The port number is the same as in the settings of the **Prp_DB** program on the PC.



12.3.2.2. PDA server settings


The server on the PDA is needed to transfer reference files and processing scheme files from the **Prp_DB** program.

The **IP address** field is unavailable for editing, it displays the IP address of the PDA in the Wi-Fi network. This IP address is used in the settings of the **Prp_DB** program (see [Synchronization of PDA and PC](#)).




12.3.3. Sending data via email

To enable the option to send data files via email, check the **Send email** option.




To send data, you need to enter the recipient's email address and select the file format (CSV, XLS, XML).



12.4. PRP measurement parameters

The **Measurement parameters settings** menu item is responsible for configuring the calculation of the controlled parameters of the rail head.

25




Calculation methods – configure the methods used to calculate rail head parameters.

Calculated parameters – select the rail head parameters to be calculated and displayed.

L parameters – set the reference point values for calculating rail parameters.

12.4.1. Calculation methods

Select the **Calculation methods** item:




Lateral wear from:
Reference profile
Wear is measured at a height of L1 from the running surface of the reference rail head.
Measured profile
Wear is measured at a height of L1 from the running surface of the measured rail head.

Lateral wear:
Inner
Lateral wear is measured on the inner side of the rail.
Outer
Lateral wear is measured on the outer side of the rail.
Inner&Outer
Lateral wear is measured on both the inner and outer sides of the rail. The maximum wear value will be displayed.

12.4.2. Calculated parameters


Select the **Calculated parameters** item:



To select or deselect a parameter, tap the desired item.
For parameter descriptions, see par. [9.2](#).


12.4.3. L parameters

Select the **L parameters** item:




For parameter descriptions, see par. [9.1](#).

To edit a parameter, tap on the parameter and enter a new value in the window that appears. After entering, tap **OK**.



13. Setting reference profiles and tolerances

Swipe right from the left edge and select **Advanced settings**.



Reference – selection of reference profile.


Tolerance – tolerance settings for the measured parameters.

13.1. Reference profile

The application allows the scanned rail profile to be compared with the reference profile.

13.1.1. Selecting and deleting the reference profile

To select a reference as the main one, you need to swipe left from the right edge and tap **Select**. The selected reference will be marked with ✓.




To clone a reference profile, tap **Clone** and enter a new profile name.

To rename a reference profile, tap **Rename** and enter the new profile name.

To delete a reference profile, tap **Delete**.

To delete multiple or all reference profiles, perform a long press on the **Delete** button to activate multi-selection mode.




The menu includes the following buttons:

 – Delete selected references.

 – Select all references.

To view the profile and parameters of the reference, tap on the desired item.




13.1.2. Uploading the reference profile to the database

The app comes with several pre-installed reference profiles.

If the required reference profile is not in the database, the user can request RIFTEK (free service) and then add the profile.

There are three ways to add a new reference to the database:

1. Copy the reference file to the device (in any standard way) and tap . Select the files you need and tap **Select**.



2. Export a profile from the database of measured profiles.
3. Export the reference file from the **Prp_DB** program.

13.2. Tolerances

The application automatically monitors whether the measured geometrical parameters exceed the specified tolerances.

13.2.1. Viewing and deleting tolerances


For tolerances, the selection of the main tolerance is not used, since tolerances are linked to reference profiles. For each reference profile, a tolerance for the calculated parameters of the rail head can be added.

In the example below, tolerances have been added for the "54E1" reference profile. When selecting "54E1" as the reference profile, the tolerance will be used with the name "54E1".

To view or edit the values, you need to tap on the name of the tolerance.

The table displays the tolerances only for the selected geometric parameters of the rail head.


The maximum/minimum critical values of the parameters are displayed in red. The maximum/minimum values of the parameters, which are close to the critical values, are displayed in orange.



To delete a tolerance, you need to swipe left from the right edge and tap **Delete**, or tap and hold the item with the tolerance name (the procedure is the same as for the references - see par. [Selecting and deleting the reference profile](#)).


13.2.2. Adding tolerances

To add a tolerance, tap  and select a reference for which the tolerance will be set.





After adding a tolerance, you must enter the boundary values for the calculated rail parameters. To do this, click on the tolerance name and go to the mode for adding controlled parameters. Initially, the list is empty. To add a controlled parameter, you

must tap  and select the parameter for which tolerances will be entered from the drop-down list. The drop-down list contains only those parameters that have been selected for calculation (see [Calculated parameters](#)).




After selecting a parameter, the limit values must be entered.





To edit a tolerance, tap the input field and select the desired value.

To save, tap . The added tolerances for the selected parameter will appear in the list.




14. PDA software update


The software version is shown in the **About** window. To open the **About** window, tap  or swipe right from the left edge and select **About**.

**34**

To check if you have the latest version, tap the **CHECK UPDATE** button. If you have the latest version installed, the app will display a corresponding message.



If you do not have the latest version installed, you will be prompted to update the application. Tap **OK** to update. The new version of the application will be downloaded and installed automatically.




The latest version of the software can also be downloaded from the website:
<https://riftek.com/upload/medialibrary/d15/rnhed80h13jb9ndrvl9n3ycnyar96wc6/prp.zip>

The update procedure is similar to installing the application.

15. Measurement procedure

15.1. Turning on the profilometer

- Before first use, charge the batteries of both the laser module and the PDA by connecting them to the charger.
- Turn on the laser module by pressing and holding the power button for a few seconds. When powered on, the red LED indicator on the laser module will flash.
- After the laser module is turned on, it will automatically establish a wireless connection with the PDA. During this process, the blue LED on the module will be lit. Once the connection is established, the LED will turn off.
- The main application window will be updated:



The **Measurement** button, as well as the Bluetooth connection and battery charge indicators, become active.

15.2. Mounting onto the rail



Attention!

When mounting the module onto the rail, avoid strong impacts of its supports against the rail, as this may cause the profilometer to malfunction.



You need to inspect periodically the output window and basic supports of the laser scanning module and to clean them of dirt.

Do not clean the glass by using abrasive and aggressive cleaning agents.

To perform the measurement:

- Secure the laser module onto the rail using the clamps.




To reduce the scanning time, you can manually move the carriage to the start position.

15.3. Quick setup

The main window contains tools that allow the user to quickly configure the reference.


- To quickly select the reference, tap on the current reference () and make a selection.




15.4. Measurement

To reduce the scanning time, you can manually move the carriage to the start position.

- Tap the **Measurement** button on the PDA screen. The application will request the calibration parameters of the laser module, and if the parameters are successfully read, the measurement window will appear.




- When you tap the **Measurement** button, the laser module will scan the rail head surface. The scanning time is 10-12 seconds, during which the red LED lights up.
- After the scanning is complete, the PDA will show the values of the measured parameters selected for display:



38

If the tolerance for the selected reference is specified in the settings, the parameter value will be marked with a green icon. If the parameter exceeds the specified tolerance, the value will be marked with a red (orange) indicator:



- When you tap the **Measurement** button, the laser module will re-scan the rail head surface (if required).


The application allows the user to display only the parameters of the measured profile and remove the graphical representation of the profile. To do this, uncheck the **Reference profile** and **Show chart**, respectively.



- If a calibration block or reference rail was scanned for verification, the scan results must not differ from the nominal values by more than 0.1 mm. In this case, the device is ready for operation. Otherwise, it must be calibrated according to the instructions.


15.4.1. Saving the measured profile

- To save the measured profile, tap the **Save** button () and enter the rail identification parameters.



The measurement will be saved to the database (see [Viewing measurement results](#)).


If a measurement with the entered parameters already exists in the database, a warning message will be displayed:



The new measurement can either overwrite the existing one or be canceled.

16. Browsing the database

To view the saved data, go to the main menu (tap , or swipe right from the left edge of the screen) and select **Measurement Data**.




A list of saved rail measurements will be displayed on the screen.

16.1. Data export


To export multiple or all measurements, perform a long press on the desired entry to activate multi-selection mode. You can optionally filter the required data beforehand (see [Data filtering](#)).

41



Next, select the data to be exported to the PC and tap the **Export data** button ().

If multiple export options are selected in the export settings, a menu with export format options will appear on the screen.



- To export to the PC, select **Export to Prp_DB**.


Attention!

For successful data export:

- The smartphone must be connected to a Wi-Fi network.
- The Prp_DB application must be running on the PC.
- The correct IP address must be set in the PC server settings (see [PC server settings](#)).

If the data is successfully transferred, a pop-up confirmation message will appear on the screen.

In case of failure, an error message will be displayed:




- To save data to the smartphone, select **Save to smartphone**.
The data will be saved to the internal memory in the **\\Download** folder.
- To send data by email, select **Send email**.
The data will be sent to the email address specified in the settings.

Attention!


For successful data transmission, the smartphone must be connected to the internet via a wireless network.

16.2. Data deletion

To delete a locomotive/car, swipe left from the right edge and tap **Delete**.




To delete multiple or all entries, perform a long press on an entry to activate multi-selection mode.



Next, select the data to be deleted and tap the **Delete item(s)** button .


16.3. Data filtering

To add a filter, tap the **Filter** button (), and then select the fields by which the data will be filtered. Filtering can be performed by date, station, and line number.




44


Example of filtering by the **Date** parameter:



Next, tap the date selection icon () and choose the desired date.




To apply the filter, tap . The list will display only the measurements that match the filter criteria.



You can also filter the data for a specific time period. To do this, activate the **Period selection** toggle and choose the desired time range in the calendar.




To add a filter by **Station** or **Line Number** of the locomotive/wagon, select the desired value from the dropdown list.



To remove the current filter, tap the **Filter** button () and deactivate the toggle switch.

16.4. Viewing measurement results

To view measurement results, tap on the desired entry. A list of measurements will open.



In this mode, it is also possible to delete and export data.

16.4.1. Saving a profile as a reference

You can also save the profile of the selected rail as a reference. To do this, swipe the entry from right to left and tap **Save**.



Next, enter the reference profile name and tap  to save it.




48

The saved reference profile can be viewed in the reference profile database (**Advanced settings > Reference**, see [Reference profile](#)).

16.4.2. Viewing rail parameters

To view the parameters and profile of the selected rail, tap on the corresponding entry.




The window displays the identification data of the measured rail, the measured profile, and the calculated parameters.

There is an option to hide the reference profile display – simply uncheck the **Reference profile** option.


16.4.3. Graphic representation of the rail profile

The profile can be zoomed in by placing two fingers on the profile simultaneously and spreading them apart without lifting them from the screen.



17. Data exchange between smartphone and PC


To exchange data between the mobile device and the PC, select the device by navigating to **File > Device > Mobile Device**.




17.1. Wi-Fi data transfer settings

Wi-Fi is used for data transfer between the mobile device and the PC. To establish the connection, follow these steps:

1. Select the synchronization type: **Mobile device > Synchronization > WiFi**.




2. Go to the server settings: **Settings > DB, Server settings.**



For data transfer, the PC and the mobile device must be connected to the same Wi-Fi network. This can be a dedicated network created on the Android device (a virtual hotspot) or any home/office network.

Prp_DB server port settings:

Port (non-editable) – the port number used to connect the mobile device (default: **8090**).



Mobile device server settings:

Port (non-editable) – the port number (default: **8091**).

IP address – the IP address of the mobile device on the network, used by the **Prp_DB** program to connect.

The IP address must match the value specified in the mobile application settings.



17.2. Wireless data transfer

When the Wi-Fi synchronization type is selected, the following data exchange options with the mobile device become available:

- Transfer of the database file.
- Transfer of the reference profile file.


17.2.1. Transferring the database file to the PC

During Wi-Fi synchronization, the measured data is exported from the PRP mobile application.

17.2.2. Transferring the reference profile file


To transfer a reference profile file from the PC to the PDA, follow these steps:

- Select **Mobile device > Reference file > Export**.



- Select the desired file with the **.ref** extension.

If the transfer is successful, a confirmation message will appear:



17.2.3. Importing the Railset.xml file

If a wireless network is unavailable, the measured data can be exported to a file on the smartphone or sent via email.




Attention!

To import into the **Prp_DB** database, the file must be in XML format (**Railset.xml**).

Next, copy the **Railset.xml** data file to the PC and import it into the **Prp_DB** database.


- Select **Synchronization > WiFi**.



– Select **Mobile device > Import Data**, or click the **Import Data** button.



– Select the **Railset.xml** data file.



The measured profiles will be imported into the database.


18. Installing software on PC

18.1. Database support software installation

The **PRP_DB** software is intended for maintaining the rail wear database on a personal computer.

To install the software, insert a compact disk to PC CD drive, select and start **Install_PRP.exe** file in the **Software** folder. Follow instructions of the installation wizard. By default, the program is installed in **C:\Program Files (x86)\Riftek, LLC\Prp_DB**.

18.2. Synchronization of mobile device and PC




18.3. Launching the software

To launch the program, select:

Start > All programs > Riftek, LLC > PRP_DB > Prp_db.exe


The main window appears as follows:



19. User settings of the program

19.1. Parameter settings

Select **Settings > Parameters** in the main window, or click .



The **Parameters** window contains four tabs:

- Rail parameters
- Calculated parameters
- L-parameters
- Measurement method

19.1.1. "Rail parameters" tab

In this tab, you can select parameters, which will be displayed on the screen when browsing the database.

Name	Show/Hide
Measurement date	<input checked="" type="checkbox"/>
Measurement time	<input checked="" type="checkbox"/>
Station	<input checked="" type="checkbox"/>
Line number	<input checked="" type="checkbox"/>
Rail number	<input checked="" type="checkbox"/>
Distance	<input checked="" type="checkbox"/>
Operator	<input checked="" type="checkbox"/>
Rail type	<input type="checkbox"/>
Side	<input checked="" type="checkbox"/>
Reference	<input checked="" type="checkbox"/>

If the parameter is selected, its value will be shown in the table of results and in the table of profiles.

19.1.2. "Calculated parameters" tab

In this tab, you can select the geometrical parameters, which will be calculated and displayed on the screen when browsing the database.

Rail parameters Calculated parameters L-parameters Measurement	
Name	Show/Hide
Vertical wear (Hv)	<input checked="" type="checkbox"/>
Side wear (Hh)	<input checked="" type="checkbox"/>
Reduced wear (Hr)	<input checked="" type="checkbox"/>
Side wear 45' (Hh45)	<input checked="" type="checkbox"/>
Reduced wear 45' (Hr45)	<input checked="" type="checkbox"/>
Rail width (W)	<input checked="" type="checkbox"/>

The description and functions of parameters see in par. [9.2](#).

19.1.3. "L-parameters" tab

In this tab, you can set the values of L-parameters.

Rail parameters Calculated parameters L-parameters Meas		
Code	Value	
Parameter L1	13,00	mm
Parameter L2	20,00	mm

The description and functions of L-parameters see in par. [9.1](#).

19.1.4. "Measurement method" tab

In this tab, you can select the measurement method.

Calculated parameters | L-parameters | Measurement method

Units measure

mm

inch

Vertical wear from:

Reference profile

Measurement profile

Auto-alignment

Yes

No

Side wear:

Inner

Outer

Inner&Outer

The description and functions of measurement methods see in par. [12.1](#).

19.1.4.1. Selection of measurement units


All parameters and measurement results can be in the Metric system (millimeters), or in the English system (inches).

To set the units of measurement, you need to select **mm** or **inches** in the **Units of measurement** field. After saving the changes, all information will be displayed in the selected units of measurement.

19.2. Database settings


19.2.1. Setting the path to database

It is possible for the user to change the drive and the directory of the profiles database storage. In the main window, select **Settings > DB, Server settings**.




Next:

- Click **Ok**.
- Specify a new path to the database.
- Confirm the creation of a new database.




All database files will be copied to the specified path.



19.2.2. Creation of empty database

To create an empty database, select **File > New DB**.




All data except the reference files will be deleted from the database. At the same time, the **DB(dd.mm.yy)** directory will be created in the installation directory where to all the deleted data will be copied (**dd.mm.yy** – current date). If necessary, these data can be restored.

19.2.3. Import of database

To import data to the database from the other database, you need to:


- Select **File > Import Data**.
- Select the directory with DB files in the left window. All files will appear in the right window:



- Click **OK** to import data.

19.2.4. Language selection

To change the language, select **Settings > Language** and select the required language support file.



19.2.4.1. Preparation and installation of the language support file

The user can change the language, form his own language support files as well as change/edit the terminology used. Language support files are located in the directory used in the process of installation. By default, the following directory is used: **C:\Program Files (x86)\Riftek, LLC\kp5_db\Language**.

The directory contains two files, **RUS.Ing** and **ENG.Ing**, to support Russian and English languages respectively.

To create the support file for any other language, it is necessary to:

- copy one of the existing files, for example - **ENG.Ing**, under the other name, for example - **DEU.Ing**;
- edit the renamed file by using any text processor, namely, change all terms and phrases to analogous ones from the required language;
- save the edited ***.Ing** file in the **Language** directory.


To edit the terminology, it is necessary to:

- edit the corresponding language file by using any text processor;
- save the edited ***.Ing** file in the **Language** directory.



19.3. Registration data

19.3.1. Registration of organizations

To add/chose the user organization, select **Registration > Organization**. Subsequently, this information will be used in automatic generation of reports.



Buttons:

 Add	Add a new organization
 Delete	Delete the selected organization
 Edit	Edit the selected organization
 Exit	Exit the mode

To select a current organization:


- Click **Edit**.
- Tick the depot.
- Click **Save**.


Organization

Code

Name


Full name

 Save




 Cancel

19.3.2. Registration of operators

Steps to follow: **Registration > Operator**. Operators data are used for identifying operators by **Number**.



Number	Name
1111	Ivanov
2222	Petrov


 Add  Delete  Edit  Exit

Functions of buttons are similar to those in par. [19.3.1](#).

19.3.3. Registration of reference profiles

The program comes with several preset profiles. In addition, the user can form a description of the required profile himself or request it from **RIFTEK** (free service).

To browse available profiles, select **Registration > Reference**:



The window of profiles displays the table with the list of reference profiles saved to database, and a graphical view of selected profile.

Buttons:

 Delete	Delete the reference profile
 Import	Import the reference profile from *.ref file
 Export	Export the reference profile to *.ref file
 Exit	Exit the mode

19.3.3.1. Request and registration of the profile file

To get the **.ref** file of the reference profile, send the drawing of profile to **RIFTEK** (info@riftek.com). Register the received **.ref** file as follows:


- Click **Import**.
- In the window appeared indicate the way to the **.ref** file.
- Click **Open**.

The profile will be added to the base of reference profiles.

20. Working with profilograms and wear calculations

20.1. Browsing the graph and profile coordinates


To browse the saved profiles, select **Database > Profiles**, or click the **Profiles** button -  .



At the left side of the window you can see the **Table of profiles** tab, which contains a list of saved profiles. The table displays only those identification parameters that were selected in the parameters window (see par. 19.1).


When selecting a profile, it is possible to browse a graphical image and geometric parameters of the measured rail. To browse the coordinates of the selected profile, you need to click the **Profile Values** button. After that, an additional tab will appear.

Buttons:

	Show/hide the Profile Values tab
	Show/hide the Profile alignment tab
	Save the profile image to file (.bmp file)
	Print the profile image
	Change the background color of the graph
	Zoom in/out the profile graph
	Calculate geometric parameters

20.2. "Parameters" tab

Calculated geometric parameters of the profile as well as L-parameters values are displayed on the **Parameters** tab, which is at the bottom of the window.



Code	Value	
Parameter L1	13,00	mm
Parameter L2	20,00	mm

Code	Parameter	
Vertical wear (Hv)	-1.90	mm
Side wear (Hh)	3.11	mm
Reduced wear (Hr)	-0.34	mm
Side wear 45° (Hh45)	1.75	mm
Reduced wear 45° (Hr45)	-1.02	mm
Rail width (W)	66.35	mm


20.2.1. Selecting a profile to compare

There are two ways to compare:

- with the reference profile,
- with the measured profile.

To compare the measured profile with the reference one, it is necessary to tick the **Reference** box.

When comparing with the reference profile, select the required reference profile in the drop-down list.



To compare two measured profiles, it is necessary to tick the **Measured** box. The **Table of profiles** tab will show an additional table for selecting a profile to compare.

20.2.2. Selecting L-parameters values

When calculating the geometric parameters, the specified support points are used. There are two variants of L-parameters:

- General parameters
- Profile parameters

When selecting **General parameters**, values of L-parameters will be taken from the default parameters file (see par. [19.1.3](#)).

When selecting **Profile parameters**, values of L-parameters will be taken from the profile file, i.e. the values, which were set in PDA when measuring the rail.

Values of L-parameters are displayed on the screen in the table of parameters.

Code	Value	
Parameter L1	13,00	mm
Parameter L2	20,00	mm

If necessary, it is possible to edit any value and to recalculate values of geometric parameters of the flange. To do it, click **Calculate**. Parameters of the measured profile and selected reference will be recalculated.

20.2.3. Geometric parameters of the profile

The table of calculated geometric parameters displays only those parameters, which were selected in the parameters window (see par. [19.1.2](#)).


Code	Parameter	
Vertical wear (Hv)	-1.90	mm
Side wear (Hh)	3.11	mm
Reduced wear (Hr)	-0.34	mm
Side wear 45' (Hh45)	1.75	mm
Reduced wear 45' (Hr45)	-1.02	mm
Rail width (W)	66.35	mm

63

20.3. Wear calculation

20.3.1. Fast wear calculation

To obtain fast calculation of the profile wear at a certain point relative to the reference, put cursor bar to any of the profiles, and when a cross-like (+) mouse cursor appears press the left mouse key. The resulting screen will show the value of the coordinate difference between profiles taken along X- and Y-axes, as shown by arrows:



To remove size indication from the screen, it is necessary to put cursor to any of the profiles and press the right mouse key.

20.4. Browsing and saving a profile

To browse the table of values, it is necessary to select **Profile Values > Wear**. The table will show deviations of the selected profile from the reference profile in two directions (X and Y).

N	Values	
	on axis X	on axis Y
1	-27,31	1,36
2	-27,36	1,39
3	-27,41	1,41
4	-27,45	1,44
5	-27,50	1,46
6	-27,59	1,48
7	-27,68	1,49
8	-27,77	1,50
9	-27,86	1,52

20.4.1. Export to Excel, DXF, REF


To export the table to the Excel or DXF format or to create the reference file (REF), it is necessary to right-click on the table. The pop-up menu will appear:




Select the needed menu item.

20.5. Alignment of profiles

To align the profiles relative to the reference profile, you need to click the **Alignment** button. The program will display an additional tab, where you can move the selected profile to the required position by using the arrows.



Next, specify the translation step and move the profile by using the **Up/Down, Left/Right** buttons.



To save the changed profile, go to the tab of identification parameters of the profile and click **Save**.

Table of profiles
Save

Rail parameters

Organization:

Measurement date:

Station:

Line number:

Rail number:

Distance:


Operator:

Side:

To create a new profile, it is necessary to change the identification parameters of the profile.


20.6. Superposition of profiles

To superimpose several changed profiles, you need to tick the required profiles in the left table. Selected profiles will be displayed in different colors.



20.7. Rescaling


To change the image scale, mark a part of the image with the left mouse key, move the image by holding it with the right mouse key pressed, or with buttons **Increase** - , **Decrease** -  and **Show all** - .



21. Viewing and editing data

21.1. Viewing and filtering data

Select **Database > Table** in the menu or click the **Table** button - . The form with results will be as follows:



- **Hide/show the field**

The table displays the identification and geometric parameters of the rail, which are selected for displaying in the parameters settings (see par. [19.1.1](#) and [19.1.2](#)).

- **Data sorting**

To sort data for any of the fields, click the left mouse key on the header of the field column:

Measurement date	Measurement time	Line number
15.02.2016	14:28:02	32
15.02.2016	16:56:29	1235.9450
15.02.2016	17:00:03	1235.9450
15.02.2016	17:00:43	1235.7778



Measurement date	Measurement time	Line number 
15.02.2016	17:00:43	1235.7778
15.02.2016	16:56:29	1235.9450
15.02.2016	17:00:03	1235.9450
15.02.2016	14:28:02	32

To cancel data sorting, press the **Ctrl** key and click the left mouse key on the header of the field column.

- **Data filtering**

In order to filter data in any of the fields, click the left mouse key on the header of the field grouping, and select the required value in the emerged drop-down list:

Measurement date	Measurement time	Line number 
15.02.2016	17:00:43	(All)
15.02.2016	16:56:29	(Custom...)
15.02.2016	17:00:03	<input type="checkbox"/> 1235.7778
15.02.2016	17:00:03	<input type="checkbox"/> 1235.9450
15.02.2016	14:28:02	<input type="checkbox"/> 32



Measurement date	Measurement time	Line number 
15.02.2016	17:00:43	1235.7778

To cancel filtering, all steps should be taken in the reverse order.

- **Data grouping**

To group data for any of the fields, click the left mouse key on the header of the field column, and, with the mouse key pressed, drag it onto the table header:

Measurement date	Measurement time	Line number
15.02.2016	17:00:43	1235.7778
15.02.2016	16:56:29	1235.9450
15.02.2016	17:00:03	1235.9450
15.02.2016	14:28:02	32



Measurement date	Measurement time	Line number
Measurement date : 15.02.2016		

• **Changing of the field position order**

To change the field position, click the left mouse key on the header of the field column and, with the mouse key pressed, drag it to the required position:

Measurement date	Measurement time	Measurement date	Line number
15.02.2016	17:00:43	1235.7778	
15.02.2016	16:56:29	1235.9450	
15.02.2016	17:00:03	1235.9450	
15.02.2016	14:28:02	32	



Measurement time	Measurement date	Line number
17:00:43	15.02.2016	1235.7778
16:56:29	15.02.2016	1235.9450
17:00:03	15.02.2016	1235.9450
14:28:02	15.02.2016	32

Buttons:


	Add a profile
	Delete the selected profile
	Delete all profiles
	Edit the selected profile
	Export the profile coordinates to the Excel format
	Report preparation

21.2. Editing data

You can edit, add and delete data in/from the database.

• **Editing data**

To edit the current entry, click and input/change the values of parameters. Click the **Save** button.



Parameters	Values	
Vertical wear (Hv)	0,01	mm
Side wear (Hh)	0,88	mm
Reduced wear (Hr)	0,45	mm
Side wear 45' (Hh45)	0,32	mm
Reduced wear 45' (Hr45)	0,17	mm
Rail width (W)	66,35	mm

- **Adding data**

To add a new data entry, click  and type the values of parameters. Click the **Save** button.

- **Deleting data**


To delete the current entry, click  and confirm the deletion.



- **Deleting all selected data**

If it is necessary to delete not only one entry but several entries combined by some condition, filter the data according to the corresponding attribute (see par. [22.1](#)),


click  and confirm the deletion.



21.3. Report preparation


When staying in the mode of scanning and editing data, the user can prepare reports in **Excel**, **RTF**, **PDF** formats, or print out reports. When preparing the report, the sorting used at the moment is taken into account.

To generate a report, press the **Report** button. The program will offer to select the following options:




21.3.1. Excel-format report

To prepare a report in Excel format, select **Report in Excel** and click **OK**.




21.3.2. Report for printout

To prepare the report for printout, select **Report for printout** and click **OK**. Data will be presented in the form of report ready for printout.



The top toolbar contains the following buttons for operating with reports:


- To printout the report, click
- To save in PDF format, click
- To save in Excel, RTF or PDF, click and select the format you need:




22. Taking measurements under PC control (without PDA)

The laser scanning module (RF570) can work under direct control of PC without PDA. To work under direct control of PC, it is necessary to select **File > Device > Profilometer**.

70



In the main menu of the program, the **PDA** tab will be replaced with the **Profilometer** tab.




The menu contains two available items:

- Calibration
- Measurement

Before you start working with the profilometer, it is necessary to set the COM port for Bluetooth connection between the laser scanning module and PDA. The procedure is described in the User's manual that comes with the Bluetooth adapter.

22.1. Calibration

To calibrate the device, select **Profilometer > Calibration**, or click




71

22.1.1. Bluetooth connection

Select the COM port and click the **Connect** button.



If the connection is successful, the device will be identified, and calibration parameters will be obtained. The status will be changed to **Connected**.




The table of calibration parameters:

Parameter	Value
Initial scanning position	1
Final scanning position	1955
Angular position increment*100000(dCorPos)	10856
Radius of turn (Radius)	5244
Correction factor(KoefA)	21
Correction factor(KoefY)	10000
Corner of turn(Alfa)	-87
Additional constant Y-axis(BaseY)	1000

Buttons:




	Reading calibration parameters
	Writing calibration parameters
	Automatic setting of calibration parameters

 The **Auto calibration** button will be active, if at least one measurement of the profile is performed and the reference profile is selected.

22.1.2. Calibration of the profilometer

- Place the profilometer on the calibration block.
- Select the reference profile from the list (**Compare > Reference**).
- Perform the measurement (the **Measurement** button)
- Perform the calibration (the **Autocalibr** button).
- Save calibration parameters (the **Write param.** button).




Calibration parameters can be set manually. To do it, click the left mouse key on the field of the required parameter value, and enter the new one.

 **Attention!** Writing incorrect values of some parameters can lead to the incorrect work of the device.

Buttons functions, work with profiles and calculation of required parameters are described in par. [20](#).

22.2. Measurement by using PC

Select **Profilometer > Measurement**, or click  .




When the Bluetooth connection is established (see par. [22.1.1](#)), the **Measurement** button is active.

22.2.1. Saving data

- Place the profilometer on the rail.
- Perform the measurement (the **Measurement** button).
- Enter the identification parameters of the rail.

Rail parameters

Organization	Locomotive departm
Measurement date	29.02.16
Station	Station
Line number	7765.454
Rail number	1123
Distance	109900
Operator	2222
Side	L



- To save results, click **Save**.
- The measured profile will be saved to the database.

Button functions, work with profiles and calculation of required parameters are described in par. [20](#).

23. Annex 1. Charging procedure

- Switch off the PDA (laser module).
- Connect the charging device to PDA (laser module).
- Connect the charging device to 220V AC.
- Time of charging: PDA - 4 hours, laser module - 5 hours. Full-charge indication: PDA - blue LED is lit; laser module - green LED is lit.
- Disconnect the charging device from 220V AC.
- Disconnect the charging device from PDA (laser module).



Attention! Please follow the sequence of these points.

24. Annex 2. Testing and calibration


We can supply the profilometer complete with the RF570.20.100 calibration-rail simulation unit (Fig. [1A](#)) and the **RF570Calibr** calibration program, which are designed for periodic testing and calibration of the profilometer.

Instead of the calibration unit, use can be made of the rail with known profile entered to the database.


Before start the testing and calibration process, it is necessary to set the COM port for Bluetooth connection between the laser scanning module and PDA. The procedure is described in the user manual that comes with the Bluetooth adapter.

24.1. Preparation for testing/calibration


- Install the **RF570Calibr** program on the PC.
- Install Bluetooth-connection between the scanning module and PC.
- Place the profilometer on the calibration unit.
- Start the **RF570Calibr** program.



- To establish the Bluetooth connection, select the required port.




The device will be identified, and calibration parameters will be read.



To perform the measurement:


- Go to the **Profile** tab.
- Select the reference profile: tick **Compare** and select the required reference profile from a drop-down list.
- Click the **Measurement** button.



24.2. Calibration

To carry out the automatic calibration, follow the steps below:

- Select the reference profile from the list.
- Perform the measurement (the **Measurement** button).
- Perform the calibration (the **Autocalibr** button).
- Go to the **Parameters** tab and save parameters (the **Write parameters** button).



If, for some reason, the parameters have incorrect values (negative or zero), you must restore the factory settings by pressing the **Load default** button. After that, recalibrate the profilometer.




Figure 1A

25. Warranty policy

Warranty assurance for the Portable Rail Profilometer PRP Series – 24 months from the date of putting in operation; warranty shelf-life – 12 months.

26. Revisions

Date	Revision	Description
30.05.2012	1.0.0	Starting document.
15.03.2018	2.0.0	Updated the PRP description and the software description.

27. Distributors

AUSTRALIA

**Applied Measurement
Australia Pty Ltd**
RAILWAY INSTRUMENTS ONLY
Thornton Plaza, Unit 5,
27 Thornton Crescent, Mitcham
VIC 3132, Australia
Tel: +61 39874 5777
Fax: +61 39874 5888
sales@appliedmeasurement.com.au
www.appliedmeasurement.com.au

BRAZIL

**CAPI Controle
e Automação Ltda**
Rua Itororó, 121, CEP 13466-240
Americana-SP, Brazil
Tel: +55 19 36047068
Fax: +55 19 34681791
capi@capicontrol.com.br
www.capicontrol.com.br

CHILE

Verne SpA
Apoquindo 2818, oficina 31
Las Condes, Santiago, Chile
Tel: +56 2 228858633
info@verne.cl
jsaavedra@verne.cl
www.verne.cl

CHINA

**Beijing Gemston Mechanical
& Electrical Equipment Co.,
Ltd**
RAILWAY INSTRUMENTS ONLY
Room 613, Anfu Mansion, Fengtai
District, Beijing, China
Tel: +86 10 6765 0516
Fax: +86 10 6765 6966
Mobile: +86 137 1755 1423
dh0526@163.com
www.baoft.cn

BELGIUM

**Althen Sensors & Controls
BV**
Verrijn Stuartlaan 40, 2288 EL,
Rijswijk, Leidschendam
The Netherlands
Tel: +31 0 70 392 4421
Tel: +31 0 61 396 7830
Tel: +31 0 64 323 8393
sales@althen.nl
info@althen.nl
www.althensensors.com

BULGARIA

ASCO RAIL sp. z o.o.
**EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**
ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

CHINA

**Beijing Haiwei Lutong
Technology Co., Ltd**
Yard 1, Tianxing Street, Fangshan
District, Beijing, China
Tel: +86 10 8366 1866
Fax: +86 10 8366 1866
info@haiwlt.com
www.haiwlt.com

CHINA

**Xi'an Win-Success
Automation Technology
Co.,Ltd**
Room 3-1-1039, Iduhui Building,
No.11 Tangyan South Road
High-Tech Zone, Xi'an
Shaanxi PRC, China
Tel: +86 29 81106280
Fax: +86 29 81106285
Mob: +86 133 19271405
info@maxsensor.com
www.maxsensor.com

BOSNIA AND HERZEGOVINA

ASCO RAIL sp. z o.o.
**EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**
ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

CHILE

MOL INGENIERIA LTDA
**EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**
República de Honduras 11936
Las Condes, Santiago de Chile
Tel: +56 9 59200362
hconcha@molingeneria.com
www.molingeneria.com

CHINA

**Chongqing Wolf Industrial
Technology Co., Ltd**
Room 2307 / 2308, Light of City
international business building,
No. 19 Jiangnan Avenue, Nan'an
District, Chongqing, China
Tel: 023 62832618
Fax: 023 62832113
info@wolf-hk.com
www.wolf-hk.com

CHINA

Micron-Metrology co., Ltd
No.2, Kecheng Rd., Industrial Park
District, Suzhou,
Jiangsu Province., China
Tel: 0512 65589760
Mob: +86 189 1806 9807
sales@micron-metrology.cn
www.micron-metrology.cn

CHINA**Zhenshangyou Technologies Co., Ltd**

Rm 2205-2210, Zhongyou Hotel
1110 Nanshan Road, Nanshan
District 518054 Shenzhen, China
Tel: +86 755-26528100/8011/8012
Fax: +86 755-26528210/26435640
info@51sensors.com
www.51sensors.com

DENMARK**BLConsult**

Ryssbält 294
95 291 Kalix, Sweden
Tel: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

FINLAND**TERÄSPYÖRÄ-STEELWHEEL OY****RAILWAY INSTRUMENTS ONLY**

Juvan teollisuuskatu 28
FI-02920 ESPOO, Finland
Tel: +358 400 422 900
Fax: +358 9 2511 5510
steelwheel@steelwheel.fi
www.teraspyora.fi

GERMANY**Finger GmbH & Co. KG
OPTICAL MICROMETERS ONLY**

Sapelloh 172, 31606
Warmсен, Germany
Tel: +49 5767 96020
Fax: +49 5767 93004
finger@finger-kg.de
www.finger-kg.de

INDIA**Influx Big Data Solutions Pvt Ltd**

No:2, Krishvi, Ground Floor,
Old Airport Road, Domlur,
Bangalore - 560071, India
Tel: +91 73 37748490
Tel: +91 94 48492380
milan@influxtechnology.com
support_india@influxtechnology.com
www.influxtechnology.com

CROATIA**ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

ESTONIA**FoodLab OÜ**

Haabersti linnaosa, Astangu tn 52
13519 Eesti, Tallinn, Estonia
Tel: +372 56 363110
foodlab.ee@gmail.com

FRANCE**BLET Measurement Group S.A.S.**

1 avenue du Président Georges
Pompidou, 92500 Rueil
Malmaison, France
Tel: + 33 0 1 80 88 57 85
Fax: +33 0 1 80 88 57 93
technique@blet-mesure.fr
www.blet-mesure.fr

GERMANY**ALTHEN GmbH Meß- und
Sensortechnik**

Dieselstrasse 2, 65779
Kelkheim, Germany
Tel: +49 0 6195 7 00 60
info@althen.de
www.althensensors.com/de/

INDIA**Paragon Instrumentation
Engineers Pvt. Ltd.**

RAILWAY INSTRUMENTS ONLY
200, Station Road,
Roorkee, 247 667, India
Tel: +91 1332 272394
tanuj@paragoninstruments.com
www.paragoninstruments.com

CZECH REPUBLIC**ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

FINLAND**Kvalitest Industrial AB
EXCEPT FOR RAILWAY
INSTRUMENTS**

Ekbacksvägen 28,
16869 Bromma, Sweden
Tel: +46 0 76 525 5000
sales@kvalitest.com
www.kvalitest.com
www.kvalitest.se

GERMANY**Disynet GmbH**

Breyeller Str. 2, 41379
Brueggen, Germany
Tel: +49 2157 8799 0
Fax: +49 2157 8799 22
disynet@sensoren.de
www.sensoren.de

HUNGARY**ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

INDONESIA**PT. DHAYA BASWARA
SANIYASA**

Botanic Junction Blok H-9 NO. 7
Mega Kebon Jeruk, Joglo
Jakarta, 11640, Indonesia
Tel: +62 21 2932 5859
management@ptdbs.co.id

ISRAEL**Nisso Dekalo Import Export LTD**

1 David Hamelech Street
Herzlia 46661 Israel
Tel: +972 99577888
Fax: +972 99568860
nissodekaloltd@outlook.com
www.fly-supply.net
www.aircraft-partsupply.com

LATVIA**FoodLab OÜ**

Haabersti linnaosa, Astangu tn 52
13519 Eesti, Tallinn, Estonia
Tel: +372 56363110
foodlab.ee@gmail.com

MONTENEGRO**ASCO RAIL sp. z o.o.**
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

NORWAY**Salitec AS**

PB 468, N-1327
Lysaker, Norway
Tel: +47 23 891015
Fax: +47 92101005
mail@salitec.no
www.salitec.no

POLAND**RIFTEK EUROPE sp. z o.o.**

ul. Domaniewska 17/19, 02-672
Warsaw, Poland
info@riftek.com
www.riftek.com

ITALY**FAE s.r.l.**

Via Tertulliano, 41
20137 Milano, Italy
Tel: +39 02 55187133
Fax: +39 02 55187399
fae@fae.it
www.fae.it

LUXEMBOURG**Althen Sensors & Controls BV**

Verrijn Stuartlaan 40, 2288 EL,
Rijswijk, Leidschendam
The Netherlands
Tel: +31 0 70 392 4421
Tel: +31 0 61 396 7830
Tel: +31 0 64 323 8393
sales@althen.nl
info@althen.nl
www.althensensors.com

NETHERLANDS**Althen Sensors & Controls BV**

Verrijn Stuartlaan 40, 2288 EL,
Rijswijk, Leidschendam
The Netherlands
Tel: +31 0 70 392 4421
Tel: +31 0 61 396 7830
Tel: +31 0 64 323 8393
sales@althen.nl
info@althen.nl
www.althensensors.com

PERU**Verne Perú S.A.C.**

Las Codornices 104,
Surquillo, Lima, Peru
Tel/fax: +51 992436734
info@verne.cl
www.verne.cl

PORTUGAL**Campal Inovacoes Ferrovias Lda.**

Lagoas Park, Edifício 7, 1º Piso
Sul, 2740-244 Porto Salvo, Oeiras,
Portugal
Tel: +351 21 584 4348
campal@campal.pt
www.campal.pt

JAPAN**Tokyo Instruments, Inc.**

6-18-14 Nishikasai, Edogawa-ku,
Tokyo, 134-0088 Japan
Tel: +81 3 3686 4711
Fax: +81 3 3686 0831
f_kuribayashi@tokyoinst.co.jp
www.tokyoinst.co.jp

MALAYSIA**OptoCom InstruVentures**

H-49-2, Jalan 5, Cosmoplex
Industrial Park, Bandar Baru
Salak Tinggi, Sepang, Malaysia
Tel: 603 8706 6806
Fax: 603 8706 6809
optocom@tm.net.my
www.optocom.com.my

NORWAY**BLConsult**

Ryssbält 294,
95 291 Kalix, Sweden
Tel: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

POLAND**ASCO RAIL sp. z o.o.****EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SERBIA**ASCO RAIL sp. z o.o.****EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SLOVAKIA**ASCO RAIL sp. z o.o.**
**EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SOUTH KOREA**PROSEN. CO., LTD**

M-1001, Songdo techno park IT
center, 32, Songdogwahak-ro,
Yeonsu-gu, Incheon, 21984,
Republic of Korea
Tel: +82 32 811 3457
Fax: +82 32 232 7458
trade@prosen.co.kr
www.prosen.co.kr

SWEDEN**Kvalitest Industrial AB**
**EXCEPT FOR RAILWAY
INSTRUMENTS**

Ekbacksvägen 28,
16869 Bromma, Sweden
Tel: +46 0 76 525 5000
sales@kvalitest.com
www.kvalitest.com
www.kvalitest.se

TURKEY**MAK Elektronik Malzeme**
Analiz ve Kalite Kontrol
Cihazlari Dis Tic. Ltd. Sti.

Cenap Sahabettin Sokak, No:39,
34718 Kosuyolu - Kadikoy /
Istanbul - TURKEY
Tel: +90 216 402 10 34
Fax: +90 216 402 10 35
ulastac@metalografi.net
www.makelektronik.com.tr

**UNITED KINGDOM,
IRELAND****Althen UK**

Northamptonshire
United Kingdom
Tel: +44 0 7823 921427
t.stoyles@althen.co.uk
www.althensensors.com
www.althencontrols.com

SLOVENIA**ASCO RAIL sp. z o.o.**
**EXCLUSIVE REPRESENTATIVE
FOR RAILWAY EQUIPMENT**

ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: + 48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SPAIN**IBERFLUID Instruments S.A.**

C/ Botanica, 122, 08908
L'Hospitalet de Llobregat
Barcelona
Tel: +34 93 447 10 65
Fax: +34 93 334 05 24
myct@iberfluid.com
www.iberfluid.com

SWITZERLAND**ID&T GmbH**

Gewerbestrasse 12/a
8132 Egg (Zurich), Switzerland
Tel: + 41 44 994 92 32
Fax: + 41 44 994 92 34
info@idtlaser.com
www.idtlaser.com

TURKEY**TEKMA Mühendislik A.S.**

Cevizli Mh. M. Kemal Cd.,
Hukukçular Towers,
A-Blok, No: 66-A/39
Kartal - Istanbul
Tel: +90 216 970 1318
Tel: +90 850 840 2334
info@tekma.eu
www.tekma.eu

USA**Althen Sensors & Controls**

2531 Bradley St., Oceanside, CA,
92056, USA
Tel: 858 633 3572
r.ream@althensensors.com

SOUTH KOREA**BS Holdings**

B-201, Wonpogongwon 1ro,
59 Danwon-gu, Ansan-si,
Gyeonggi-do 15455, Republic of
Korea
Tel: +82 31 411 5011
Fax: +82 31 411 5015
bsh5011@hanmail.net
www.lasersolution.co.kr

SWEDEN**BLConsult**

Ryssbält 294,
95 291 Kalix, Sweden
Tel: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

THAILAND**Advantech Solution Co., Ltd.**

20/170 Motorway Rd.,
Kwang Pravet, Khet Pravet,
Bangkok, Thailand 10250
Tel: +662 1848705
Fax: +662 1848708
sales@advantechsolution.com
www.advantechsolution.com

UKRAINE**KODA**

Frunze st. 22, 61002,
Harkov, Ukraine
Tel/Fax: +38 057 714 26 54
mail@koda.com.ua
www.koda.com.ua

USA, CANADA, MEXICO**Acuity Products of Schmitt
Industries, Inc.**

2765 NW Nicolai Street
Portland, OR, 97210, USA
Tel: +1 503 227 7908
Fax: +1 503 223 1258
sales@acuitylaser.com
www.acuitylaser.com

USA, CANADA, MEXICO

**International Electronic
Machines Corporation**
RAILWAY INSTRUMENTS ONLY
850 River Street, Troy,
New York, USA
Tel: +1 518 268-1636
Fax: +1 518 268-1639
marketing@iem.net
www.iem.net

28. RIFTEK's measurement instruments for railway transport

81



Railway wheel profile gauge, IKP Series

Laser Profilometer IKP-5 Series is employed for:

- Measuring geometrical parameters of the wheel flange (thickness, slope, height), rim/tire thickness.
- Taking full profile of the wheel rolling surface.
- Maintaining the wear database.
- Tolerance control and sorting when checking, inspecting, repairing and forming railway wheelsets.

Measurements are made directly on the rolling stock without rolling out the wheelset.



Rail profile measurement gauge, PRP Series

The main functions of PRP are as follows:

- Obtaining information on the cross-section profile of the railhead acting face.
- Full profile scanning and analysis of the railhead acting face.
- Visualization of combined graphic images of the actual and new cross-section profiles of the railhead.



Wheel diameter measuring gauge, IDK Series

Electronic gauge is designed to measure the wheel rolling circle diameter of railway, metro and tram wheelsets.

Measurements are made directly on the rolling stock without rolling out the wheelset.



Back-to-back distance measuring gauge, IMR Series

Electronic gauge is designed to measure the back-to-back distance of railway, metro and tram wheels in the course of checkup, examination, repair and formation of wheelsets. Measurements are made directly on the rolling stock without rolling out the wheelset.



Back-to-back distance measuring gauge, IMR-L Series

Electronic gauge is designed to measure the back-to-back distance of railway, metro and tram wheels in the course of checkup, examination, repair and formation of wheelsets. Measurements are made directly on the rolling stock without rolling out the wheelset.



Disc brakes profile gauge, IKD Series

Electronic gauge is employed for laser scanning and measurement of disc brakes wear parameters.

The main functions of IKD are as follows:

- Obtaining information on the profile of the disc brakes acting face.
- Full profile scanning and analysis of the disc brakes acting face.
- Visualization of combined graphic images of the actual and new disc brakes profiles.



Real-time wheels geometry measurement system 3DWheel

The system is designed for non-contact automatic measurement of geometrical parameters of railway wheels and uses a combination of 2D laser scanners mounted wayside in the track area.

The system can be easily installed on any type of railway infrastructure.